





# GL-AR111-V2ADx-9/ GL-AR111-V2ADx-12 LED Lighting Installation Instructions

 <p>AC IN</p> <p>transformer</p> <p>luminaire</p> <p>AR111 halogen lamp</p> <p>ON</p>	 <p>AC IN</p> <p>transformer</p> <p>luminaire</p> <p>OFF</p> <p>AR111 halogen lamp</p>
<p>傳統燈具設定。 Traditional lighting setup.</p>	<p><b>步驟 1.</b> 安裝前請先關閉電源及開關。 之後依序取下傳統變壓器及 AR111 鹵素燈。</p> <p><b>Step 1.</b> First, turn off the power. Then disconnect the transformer from the system. Finally, remove the AR111 halogen lamp.</p>
 <p>AC IN</p> <p>TRIAC Dimmer</p> <p>GP-LED Driver</p> <p>DC OUT</p> <p>luminaire</p> <p>OFF</p> <p>GL-AR111-V2ADx-9 GL-AR111-V2ADx-12 LED lamp</p>	 <p>AC IN</p> <p>TRIAC Dimmer</p> <p>GP-LED Driver</p> <p>DC OUT</p> <p>luminaire</p> <p>ON</p> <p>GL-AR111-V2ADx-9 GL-AR111-V2ADx-12 LED lamp</p>
<p><b>步驟 2.</b> 將 GP- LED driver 的輸出端依正(+)負(-)極接上燈具，輸入端藍色線接上 AC; 棕色線接上調光器。 將 GL-AR111-V2ADx LED lamp 安裝上燈具。</p> <p><b>Step 2.</b> Connect the LED driver output to the positive (+) and negative (-) terminals of the luminaire. Connect the LED driver's blue input line to AC power and the brown input line to the dimmer. Attach the GL-AR111-V2ADx-12 LED lamp to the luminaire.</p>	<p><b>步驟 3.</b> 打開電源開關確認亮燈即完成。</p> <p><b>Step 3.</b> Turn on the power and ensure the lamp is working correctly.</p>