


3in 1 Dimmable Function Description (0-10V)

- ◆ Connecting a variable resistor/ 0~10 V Direct Voltage or a 10V / PWM signal can adjust the output of constant current.
- ◆ Connecting “DIM +/–” to “V +/–” may damage the LED driver.
- ◆ When the control cable DIM +/– is open, V +/– output will reach 100%.
- ◆ The output current drops down to 0% when the dimming input is about less than 7K Ω / 0.7Vdc / 10V PWM signal with 7% duty cycle.

In order to turn off the main power for the LED driver, we recommend installing an external switch.

Please refer to the diagram.

About Electronic Potentiometer Refer to: <http://www.glaciallight.com/products/PDF/GL-EC013.pdf>



- ◆ (1) 0-100K Ω Resistor Dimmable (Typical) :



Resistor Ω	Single-driver	Short	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K
	Multi-driver	Short/N	10K/N	20K/N	30K/N	40K/N	50K/N	60K/N	70K/N	80K/N	90K/N	100K/N
lout (%)		0%	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%

※The length of extended wire for DIM +/– shall not exceed 20 meters. (Wire \leq 20m)

※ N =The number of dimmer drivers should not exceed 15. (N \leq 15)

※DIM +/– <7K Ω or 7K Ω /N, lout 0%

(1)
Resistor
or
Potentiometer






◆ (2) DC : 0-10V Dimmable (Typical) :

DIM (Voltage)	0V	1V	2V	3V	4V	5V	6V	7V	8V	9V	10V
lout (%)	0%	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%

※DIM+/- <0.7V, lout 0%

(2)
0~10V




◆ (3) 10V / PWM Dimmable (Typical) :

DIM (10V / PWM)	0%	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%
lout (%)	0%	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%

※DIM+/- <7%, lout 0%

(3)
10V / PWM




3 合 1 調光功能說明 (0-10V)

- ◆ 在 DIM+ 和 DIM- 之間連接一個可變電阻或連接 0~10V 直流電壓或 10V / PWM 信號，可調整恆定電流輸出。
- ◆ 勿將 DIM+/- 與 V+/- 相連接，這樣會造成 LED 驅動器損壞。
- ◆ 當控制線 DIM+/- 開路(open)時，V+/- 輸出為 100%。
- ◆ 當調光輸入約小於 7KΩ / 0.7Vdc / 10V PWM 訊號占空比 7%時，輸出電流將降為 0%。

要達到 LED Driver 主電源(main power)完全關閉，建議安裝一個外部開關(SW)，請參考下列連接方法。

關於 Potentiometer(電位器)請參考: <http://www.glaciallight.com/products/PDF/GL-EC013.pdf>




- ◆ (1) 0-100KΩ Resistor Dimmable (Typical) :

Resistor Ω	Single-driver	Short	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K
	Multi-driver	Short/N	10K/N	20K/N	30K/N	40K/N	50K/N	60K/N	70K/N	80K/N	90K/N	100K/N
Iout (%)		0%	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%

※ DIM+/- 接線長度不可超過 20 公尺, (Wire≤20m) · ※ N=同步調光功能 LED 驅動器數目，最多不可超過 15 台 (N≤15)

※DIM+/- <7KΩ or 7KΩ/N, Iout 0%






◆ (2) DC : 0-10V Dimmable (Typical) :

DIM (Voltage)	0V	1V	2V	3V	4V	5V	6V	7V	8V	9V	10V
lout (%)	0%	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%

※DIM+/- <0.7V, lout 0%

(2)
0~10V




◆ (3) 10V / PWM Dimmable (Typical) :

DIM (10V / PWM)	0%	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%
lout (%)	0%	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%

※DIM+/- <7%, lout 0%

(3)
10V / PWM




3 合 1 调光功能说明 (0-10V)

- ◆ 在 DIM+ 和 DIM- 之间连接一个可变电阻或连接 0~10V 直流电压或 10V / PWM 信号，可调整恒定电流输出。
- ◆ 勿将 DIM+/- 与 V+/- 相连接，这样会造成 LED 驱动器损坏。
- ◆ 当控制线 DIM+/- 开路(open)时，V+/- 输出为 100%。
- ◆ 当调光输入约小于 7KΩ / 0.7Vdc / 10V PWM 讯号占空比 7% 时，输出电流将降为 0%。

要达到 LED Driver 主电源(main power)完全关闭，建议安装一个外部开关(SW)，请参考下列连接方法。

关于 Potentiometer(电位器)请参考: <http://www.glaciallight.com/products/PDF/GL-EC013.pdf>




◆ (1) 0-100KΩ Resistor Dimmable (Typical) :

Resistor Ω	Single-driver	Short	10K	20K	30K	40K	50K	60K	70K	80K	90K	100K
	Multi-driver	Short/N	10K/N	20K/N	30K/N	40K/N	50K/N	60K/N	70K/N	80K/N	90K/N	100K/N
	Iout (%)	0%	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%

※ DIM+/- 接线长度不可超过 20 公尺, (Wire ≤ 20m) , ※ N=同步调光功能 LED 驱动器数目, 最多不可超过 15 台 (N ≤ 15)

※ DIM+/- < 7KΩ or 7KΩ/N, Iout 0%






◆ (2) DC : 0-10V Dimmable (Typical) :

DIM (Voltage)	0V	1V	2V	3V	4V	5V	6V	7V	8V	9V	10V
lout (%)	0%	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%

※DIM+/- <0.7V, lout 0%

(2)
0~10V



◆ (3) 10V / PWM Dimmable (Typical) :

DIM (10V / PWM)	0%	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%
lout (%)	0%	10%	20%	30%	40%	50%	60%	70%	80%	90%	100%

※DIM+/- <7%, lout 0%

(3)
10V / PWM

